

ELS Protector




Is to be changed into an ELS AccessManager (type identification: 36) (by entering the ELS AccessManager serial number)

Procedure:

Enter the serial number of the ELS AccessManager in the serial number box.



After confirmation of the security query the following window appears



After confirming the question with “Yes”, the ELS Protector becomes an ELS AccessManager